



USB Hard Drive User Manual

For more information, visit our website at www.oyendigital.com

(1) Specifications

Interface/Ports *	<ul style="list-style-type: none">• USB 2.0 High Speed• USB 3.0 Super Speed
Data Transfer *	<ul style="list-style-type: none">• USB 2.0 up to 480Mbps (60MB/s)• USB 3.0 up to 4.8Gbps (572MB/s)
System Requirements (PC)	<ul style="list-style-type: none">• Windows XP/Vista/7
System Requirements (Mac)	<ul style="list-style-type: none">• Mac OS 10.2 or higher
Operating Environment	<ul style="list-style-type: none">• Temperature: 5°C ~ 40°C• Humidity: 10%RH ~ 80%RH
Storage Environment	<ul style="list-style-type: none">• Temperature: -20°C ~ 70°C• Humidity: 5%RH ~ 90%RH
Power	Input: Bus power

* Available interfaces and data transfer speeds depend on the model.

(2) Detailed View

LED indicator
OFF = Power OFF
Solid = Power ON, status ready
Flashing = Power ON, read/write access

USB 2.0



USB 3.0



(3) Connecting the Hard Drive

Connecting the hard drive:

- 1) Connect the drive to the computer using the included USB cable.
- 2) Wait 5-20 seconds for the computer to recognize the drive.
- 3) The drive is now ready for use.
- 4) **(MAC Users)** As shipped, the drive provides read-only access for Mac. All Mac users must reformat the drive using the instructions in the "Formatting the Hard Drive" section of this manual.

Notes:

- Front USB ports on a desktop may not be able to provide adequate power.
- A USB port on a PCMCIA or Express Card may not be able to provide adequate power.
- If connecting to a USB Hub, make sure it is a powered Hub (one that uses an AC adapter).

(4) Formatting the Hard Drive

The drive is pre-formatted as NTFS, the preferred file system for Windows. For full functionality on Mac OS computers, you must reformat the drive before use.

To format the drive for Mac OS X:

1. Connect the drive to your computer.
2. Open Disk Utility (Applications folder > Utilities > Disk Utility).
3. From the list on the left, click on the external drive with the size in GB (not the indented item underneath).
4. Click the 'Partition' tab at the top of the application.
5. Select the drop down menu under 'Volume Scheme' and choose 1 partition (or select 2 or higher for more partitions).
6. Click 'Options' and select 'Master Boot Record' then click Ok.
7. Enter a name and select Mac OS Extended (Journaled) *.
8. Click 'Apply'. Click 'Partition' to complete the process.
9. Upon completion, the drive will be available for use.

* If you will be using the drive with both Windows and Mac, select MS-DOS from the drop down menu.

(5) Using the Hard Drive

Using the hard drive with the included software

The drive includes software (via download) that allows you to easily backup your important files. The software is not required in order to use the drive. To install the software, simply follow the steps on the included glossy card.

Using the hard drive without software

- 1) Look for the external drive in My Computer (Win) or Desktop (Mac).
- 2) Click and hold down the mouse button on the file/folder that you want to copy to the drive.
- 3) Drag the mouse over the icon representing the external drive.
- 4) Let go of the mouse button and the file will copy to the drive.
- 5) The task is complete. This is known as a "drag-and-drop" action.

Using the hard drive with Time Machine (Mac Users Only)

- 1) Make sure the drive is formatted as Mac OS Extended (Journaled) as described in the "Formatting the Hard Drive" section.
- 2) Go to the Apple Menu > System Preferences and click on the Time Machine icon. The Time Machine panel will then launch.
- 3) Click On to enable Time Machine.
- 4) Select the external hard drive and choose "Use for Backup."
- 5) You can set additional options by clicking the Options button.
- 6) Time Machine is now backing up your Mac automatically to the external hard drive.

(6) Disconnecting the Hard Drive

Windows: Close all windows and applications that are accessing the drive. Click the green "Eject Hardware" (Safely Remove Hardware) icon in the system tray and highlight the external drive. Wait for a few seconds until the system prompts "You may safely remove this device."

MAC: Close all windows and applications that are accessing the drive. Drag the external drive to the Trash/Eject icon to dismount it. After the disk icon has disappeared from the desktop, you may safely disconnect the external hard drive.

(7) Warranty Information

This product includes a two (2) year repair/replacement warranty provided by Oyen Digital. This warranty is non-transferable and is limited to the original purchaser. Warranty service may be requested by completing the form at the following link: www.oyendigital.com/rma-request-form.html

For our complete warranty policy, visit: www.oyendigital.com/warranty.html

(8) Safety Information

- The disk drive is a delicate electronic device and is susceptible to damage due to excessive physical shock. Please handle the unit with care.
- Avoid moving the drive while it is reading/writing data. Doing so can cause corruption and/or damage to the drive.

(9) FAQs

Q: Can I use my drive with bus power only?

A: Yes, in the majority of cases bus power is adequate. However, if you are using the drive with a hub, make sure that it is a powered hub (uses AC adapter).

Q: Why does my computer show that the external hard drive has less capacity than advertised?

A: In the hard drive industry the partitioned size will be less than the printed capacity on the label. This is due to the fact that computers calculate capacity based on a binary (base 2) method, where 1GB = 1024 MB. The hard drive industry calculates using a decimal method, where 1GB = 1000 MB. This is why the two different industries will report different capacities for the same drive.

For other questions please contact tech support or visit the FAQ section of our Web site (www.oyendigital.com/support.html).

Technical Support: tech@oyendigital.com