MiniPro Wii U Setup Guide

OYEN DIGITAL

Step 1: Turn off the Wii U.

Step 2: Connect the cable to the USB-C port of the MiniPro. Connect the other end into both of the USB ports of the Wii U. If you prefer to power from the AC power adapter, connect it to the MiniPro's power input. (Only one USB port is necessary if using the AC power adapter.)
Note: The eSATA port of the MiniPro is not used.

Step 3: Turn the MiniPro on. Turn on your Wii console. After a short wait, you will be prompted that you'll need to format your USB device to use it with the Wii U.

Step 4: Select "Format."
Note: After it is formatted for the Wii U, it cannot be used with a PC or Mac.

Step 5: After the formatting process is complete, you'll be returned to the Wii U Menu, and a blue icon in the lower left-hand corner will indicate that your hard drive is set-up and ready for use.

Note: For more information regarding using an external hard drive with the Wii U, please visit: https://en-americas-support.nintendo.com/app/answers/detail/a_id/1585