



USB 3.0 Hard Drive Enclosure Install Guide

(1) Specifications

Interface/Ports	<ul style="list-style-type: none"> • USB 3.0 Super Speed
Data Transfer *	<ul style="list-style-type: none"> • USB 2.0 up to 480Mbps (60MB/s) • USB 3.0 up to 4.8Gbps (572MB/s)
System Requirements (PC)	<ul style="list-style-type: none"> • Windows XP/Vista/7/8/10 or higher
System Requirements (Mac)	<ul style="list-style-type: none"> • Mac OS 10.2 or higher
Operating Environment	<ul style="list-style-type: none"> • Temperature: 5°C ~ 40°C • Humidity: 10%RH ~ 80%RH
Storage Environment	<ul style="list-style-type: none"> • Temperature: -20°C ~ 70°C • Humidity: 5%RH ~ 90%RH
Power	Input: Bus power

* Data transfer speeds depend on the host computer port and installed drive.

(2) Overview

Package Contents:

- USB 2.5" External Hard Drive Enclosure
- USB 3.0 Micro-B Cable


(3) Detailed View

LED indicator

OFF = Power OFF

Solid = Power ON, status ready

Flashing = Power ON, read/write access



(4) Installation

1. Press the button to separate the top of the enclosure from the bottom. Install a 2.5" SATA hard drive or SSD. Secure the top of the enclosure to the bottom.
2. Connect the USB connector to a USB port on your computer or powered USB Hub.
3. Connect the other end of the USB cable to the enclosure. The LED will light to indicate that power is present.

(5) Formatting

If installing a brand new drive, the drive must be formatted before it is accessible. Use Disk Management on the PC or Disk Utility on the Mac to format the drive.

Windows: <http://oyendigital.com/windows-reformat.html>

Mac: <http://oyendigital.com/mac-reformat.html>

(6) Disconnecting the Drive

Windows: Close all windows and applications that are accessing the drive. Click the green "Eject Hardware" (Safely Remove Hardware) icon in the system tray and highlight the external drive. Wait for a few seconds until the system prompts "You may safely remove this device."

MAC: Close all windows and applications that are accessing the drive. Drag the external drive to the Trash/Eject icon to dismount it. After the disk icon has disappeared from the desktop, you may safely disconnect the external drive.

(7) Warranty Information

This product includes a one (1) year repair/replacement warranty provided by Oyen Digital. This warranty is non-transferable and is limited to the original purchaser. Warranty service may be requested by completing the form at the following link: www.oyendigital.com/rma-request-form.html

For our complete warranty policy, visit: www.oyendigital.com/warranty.html

(8) Safety Information

- The disk drive is a delicate electronic device and is susceptible to damage due to excessive physical shock. Please handle the unit with care.

(9) FAQs

Q: What file system should I use to format the drive?

A: This will depend on how you want to use the drive but in general, we recommend:

- Windows 2000/XP/Vista/7/8 → NTFS
- Mac OS X → HFS+ (Mac OS Extended)
- For use with both PC and Mac → FAT32

Q: Can I use my device with bus power only?

A: This will depend on the model, the hard drive, the interface, and the host computer. Bus power is supported with Firewire and USB in most situations.

For other questions please contact technical support or visit the FAQ section of our Web site.

Technical Support: tech@oyendigital.com

Warranty Service: rma@oyendigital.com

Web Site: www.oyendigital.com