

Setup Guide

OYEN DIGITAL
High Performance Storage Solutions

Step 1: Turn off the Wii U

Step 2: Plug the MiniPro into both of the USB port(s) on the back of the Wii U using the included USB y-cable. If you prefer to power from the AC power adapter, connect it to the MiniPro's power input.

Note: Only one USB port is necessary when using the AC power adapter.

Step 3: Turn the MiniPro On. Turn on your Wii console. After a short wait, you should be prompted that you'll need to format your USB device to use it with the Wii U.

Step 4: Select "Format."

Note: This will erase any data currently on the hard drive.

After it is formatted for the Wii U, it cannot be used with a PC or Mac.

Step 5: After the formatting process is complete, you'll be returned to the Wii U Menu, and a blue icon in the lower left-hand corner will indicate that your hard drive is set-up and ready for use.

Note: For more information regarding using an external hard drive with the Wii U, please visit:

http://www.nintendo.com/consumer/systems/wiiu/en_na/system_external_storage.jsp