Xbox One - External Drive User Guide

Connecting the external drive:

- 1. Connect the external drive to a USB port on your Xbox One console.
- 2. The external drive will be recognized and ready for use.

Managing the storage device:

- 1. Settings > System > Storage.
- 2. Select the storage device and choose View Contents.
- 3. Highlight a game or app and press the "Menu" button (\equiv) on your controller.
- 4. Select Manage Game to move or copy content.

(Optional) To set the external drive as the default location for downloads: Settings > System > Storage. Select the external drive and choose 'Install Here by Default'.

Troubleshooting:

If problems exist, please try the following:

- Connect the drive to a different USB port on the Xbox One
- Turn off the Xbox and disconnect the power for one minute
- Disable the Power option: Settings > Power & Startup > Power Options > **Uncheck** "When Xbox is off, turn off storage."
- Verify the Xbox One has the most recent system update.
- Ensure that the Xbox One is logged in to your Xbox Live account.